

BeHub

Quick installation guide

About your BeHub

Cutting-edge WiFi 6 (AX) router, engineered for a powerful and seamless online experience with support for speeds of up to 2.5G, setting a new standard for connectivity.

With its advanced technology and high-quality components, this router ensures lightning-fast speeds and incredibly low latency, guaranteeing that all your online activities, from streaming to gaming, are smooth and uninterrupted. Say goodbye to buffering and lag, and embrace a top-tier surfing experience with your quality WiFi 6 (AX) router.



2.5G WAN Port



2.5G LAN Port




1G LAN Ports



WiFi 6 AX



FxS



Package Contents:



BeHub Router



Power Adapter



LAN Cable



Phone Cable



Quick Installation Guide

LED Indicators:



Not connected to the internet



Connected to the internet with WiFi OFF



Router booting up



Connected to the internet

Connect the hardware

- 1 Place your BeHub router near your internet-connected modem.
- 2 Connect the LAN cable to your modem and to the port labeled WAN on the router.
- 3 Connect the supplied power adapter to the router and a power outlet.
- 4 Turn on the router by pressing the power button and wait approximately one minute until the router finishes the initial startup.
- 5 When the LED light on the front of the device turns white, the router is connected to the internet and you can start using the internet.

* The default WiFi network name and password appear on the label on the back of the device.




Need help?

Scan the QR code or go to befibre.zendesk.com

Back Panel

Rail for wall mount bracket



Reset Button

Power Button

Phone Lines

Gigabit LAN Ports (2-4)

USB

Power Jack

2.5 Gigabit WAN Port

3

2